

French Doors in QEC

- To add French Doors to a unit, enter the Total Width to be split between two doors in the door width field.

In this example the door width is entered at 56".

- There is a checkbox labeled "French Doors" next to the "door height" input. Once this box is checked it will split the door width evenly between two doors hinged opposite from each other.

Please Note: Jamb mount style hinges can be added to a French Door unit, but only if no panels are present.